


How to use XP-Pen driver on Mac OS Mojave (10.14)

1. Please go to “*Finder – Preferences - Sidebar*”.
2. On the Sidebar tab, please make sure your *Macintosh HD (Mac)* Hard Disk is enabled.




3. Please visit the XP-Pen website (<https://www.xp-pen.com/download/index/cid/25/p/1.html>) and download and install the most recent driver until complete.

4. Open “Launchpad” and find “PenTabletSetting”.




5. Open “*System Preferences*”, then “*Security & Privacy*”.


6. *On the “Accessibility” setting, find “Unlock” first then click “PenTabletSetting” and “-” to delete it.*




7. Click the “+” button.




8. Go to **“Application”** – **“PenTablet”** folder, then choose **“PenTabletSetting”** and **“Open”** button.




9. Click the **“+”** button.




10. Go to “*Application*” – “*Macintosh HD (Mac)*” – “*Library*” – “*Application Support*” – “*PenTablet*” folder, then choose “*MsgDisplay*”, “*PenTabletDriverUX*”, “*UgeePenTabletInfo*” and “*Open*” button.



11. Make sure “*MsDisplay*”, “*PenTabletDriverUX*”, “*PenTabletSetting*”, and “*UgeePenTabletInfo*” are both enabled.





12. Close "Security & Privacy".

13. Reboot system and when system goes to the desktop, please open "PenTabletSetting" on Launchpad and set it to your XP-Pen product.