



How to use XP-Pen driver on Mac OS Mojave (10.14)

1. Please go to “*Finder – Preferences - Sidebar*”.
2. On the Sidebar tab, please make sure your *Macintosh HD (Mac)* Hard Disk is enabled.




Please visit the XP-Pen website (<https://www.xp-pen.com/download/index>) and download and install the most recent driver until complete.


3. Open “Launchpad” and find “PenTabletSetting”.




4. Open “*System Preferences*”, then “*Security & Privacy*”.
5. *On the “Accessibility” setting, find “Unlock” first then click “PenTabletSetting” and “-” to delete it.*




6. Click the “+” button.




7. Go to “*Application*” – “*PenTablet*” folder, then choose “*PenTabletSetting*” and “*Open*” button.




8. Click the “+” button.




9. Go to “*Application*” – “*Macintosh HD (Mac)*” – “*Library*” – “*Application Support*” – “*PenTablet*” folder, then choose “*MsgDisplay*”, “*PenTabletDriverUX*”, “*UgeePenTabletInfo*” and “*Open*” button.



10. Make sure “*MsDisplay*”, “*PenTabletDriverUX*”, “*PenTabletSetting*”, and “*UgeePenTabletInfo*” are both enabled.





11. Close “Security & Privacy”.
12. Reboot system and when system goes to the desktop, please open “PenTabletSetting” on Launchpad and set it to your XP-Pen product.